

## Tennis Machine Features and Use Instructions



### Features:

- **Full Court Oscillator:** Delivers balls randomly across the court.
- **Five Second Set Up:** Open the hopper, add up to 110 balls and your training is under way.
- **Battery Life:** Two to three hours per charge. Enough for a serious workout. And if you do need more battery life there is an optional External Battery Pack.
- **Versatile Speed:** 10-75 mph.
- **Variable Ball Feed:** 1-1/2 to 10 second interval.
- **Trajectory Control:** Manual from groundstroke to lob so you can practice all the shots, including overheads.
- **Interval Control** Sets the time between ball throws from one ball every 1-1/2 seconds for rapid volleys, to one ball every ten seconds.

### Use Instructions

- Turn the Tennis Machine on once in place.
- Turn on Topspin if you would like
- Turn on Oscillator to have the machine shoot the ball in a random pattern and location
- Adjust the ball speed from 1 to 10 which equates to 10MPH to 75 MPH
- Adjust the ball feed from 1 to 10 which equates to delivery of the next ball between 1.5 seconds and 10 second intervals

